

正面



User Manual 雷神机械键盘 使用说明书

使用本产品前请仔细阅读说明书, 妥善保管以备参考。 Please read the instructions carefully before using this product and keep it well for referen.

产品规格

Table with 2 columns: Product Type, Model, Cable Length, Interface, Compatibility, Dimensions, Weight.

产品特点

- Cherry MX mechanical switches with 5000 clicks... 6-key rollover... adjustable backlighting... no macro recording required.

包装内容

雷神键盘\*1、说明书\*1、保修卡\*1、合格证\*1

1

系统需求

Windows XP / Vista / Win 7 / Win 8 / Win 10 / Mac OS

产品安装

即插即用: 只需将键盘连接到可用的计算机USB端口

键盘功能

Table with 2 columns: Activation Method, Function Description. Lists Fn+F6 (Game mode), Fn+F7 (Mute), Fn+F8 (Volume Down), Fn+F9 (Volume Up), Fn+F10 (Play/Pause), Fn+F11 (Previous Track).

2

Diagram showing Fn key combinations: Fn+F12 (Next Track), Fn+Ins (Switch to 6-Key Rollover), Fn+Del (Switch to N-Key Rollover), Fn+Home (Instant Macro Recording).

即时宏录制

步骤1: 按下FN+F6, 开启Windows按键锁... 步骤2: 按下FN+Home, "G"指示灯将会快闪... 步骤3: 指定要保存宏的按键... 步骤4: 选择FN以外的按键, 录入宏列表中的内容... 步骤5: 按下FN+Home, 完成即时宏录制.

3

Diagram showing Fn key combinations for backlighting: Fn+Up (Increase brightness), Fn+Down (Decrease brightness), Fn+Left (Backlight mode), Fn+Right (Backlight mode), Fn+Win (Game mode lock), Fn+Esc (3s restore), B+L (Factory reset).

【废弃电器电子产品回收处理管理条例】

雷神倡导环保和低碳的消费体验, 建议拥有该产品的用户在不需要此产品时, 应遵守国家废弃电器电子产品回收处理相关法律法规...

4

背面

有害物质或元素名称及含量

Table with 2 columns: Component Name, Content. Lists elements like Pb, Hg, Cd, Cr(VI), PBB, PBDE.

本表格依据SJ/T 11364的规定编制... 表示有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下...

5

Specifications

Table with 2 columns: Genre, Model, Cable Length, Interface, Operational system, Dimensions, Weight.

Features

- Cherry MX switches rated at 50-million keystrokes... 6-NKRO(Default)/Full-NKRO switching... Lighting effect adjustment... No drive instant macro recording.

Package Contents

Keyboard\*1、Quick Start Guide\*1、Warranty card\*1、Qualified Certificate\*1

6

System Requirements

PC with available USB port Windows XP / Vista / Win 7 / Win 8 / Win 10 / Mac OS

Installation

Plug and play, Simply connect the keyboard to an available USB port

Keyboard function

Table with 2 columns: Hotkey, Description. Lists Fn+F6 (Game mode), Fn+F7 (Mute), Fn+F8 (Volume Down), Fn+F9 (Volume Up), Fn+F10 (Play/Pause), Fn+F11 (Previous Track).

7

Diagram showing Fn key combinations: Fn+F12 (Next Track), Fn+Ins (Switch to 6-Key Rollover), Fn+Del (Switch to N-Key Rollover), Fn+Home (Instant Macro Recording).

Instant Macro Recording

Step 1: Press FN+F6, Turn on the Windows key lock... Step 2: Press FN+Home, "G" indicator will flashing... Step 3: Assign a key you want to save macro... Step 4: Select a key other than Fn and Type key... Step 5: Press FN+Home, finish instant macro record.

Step 3 if the button is lit with backlight, Represents that the key has been set as a macro key.

8

Diagram showing Fn key combinations for macro key settings: Fn+Up (Adjust brightness), Fn+Down (Limit Game mode/Caps/Num LED), Fn+Left (Switch backlight mode), Fn+Right (Switch backlight mode), Fn+Win (Disable/Enable Win key), Fn+Esc (Profile restore).

To clear recorded Macro Key: repeat the recorded program by pressing the button to cancel the saved Macro. In step 4, do not enter the content, skip to step 5, that is, complete the action of restoring the preset value of a single key.

A single Macro Key length can be set to 42 keys. Fn cannot be set to Macro Key.

10